

## Eisenwall® Warm Weather Tips

During the warm weather months there are a few basic tips that will be beneficial to the consistent performance of Eisenwall Premium Plaster Cement.

1. Keep Eisenwall out of direct sunlight whenever possible.
2. Do not over mix nor retemper Eisenwall. The material will not reach its full strength and will be soft.
3. Bleed warm water from your water hose before mixing.
4. Mix enough Eisenwall to be applied within a twenty-minute period before mixing another batch.
5. Dump complete mixer before mixing new batch.
6. When doing production work, it is essential that the float men stay close to the nozzle man. If the float men get behind, you need to washout the pump and help catch up before the material freezes on the wall.
7. Remember Eisenwall is greatly affected by the sun so care should be given when working on walls in direct sunlight.
8. You can add up to 2-packets of Set Control per 88lb sack of Eisenwall. Each packet will add an additional 10-15 minutes of working time.
9. It is especially important to keep the mixer blades and hopper washed down to avoid material build up that could break off and cause hose packs.
10. Moist cure Eisenwall before it loses its wet sheen.

## **Eisenwall® Cold Weather Tips**

During the cold weather months there are a few basic tips that will be beneficial to the consistent performance of Eisenwall Premium Plaster Cement.

1. Use of warm water will accelerate the set time.
2. It is important to moist cure even though the walls have a wet appearance.
3. Keep material covered or in an enclosed area.
4. Try to start on the wall that has the sun on it in the morning and finish at least 2 hours before sunset.