



Concrete Pharmacy® LIGHT — DATASHEET

PRODUCT DESCRIPTION:

By adding LIGHT from the Concrete Pharmacy® your cement, concrete, mortar, plaster, and grout mixtures will become lighter in color. Use increased quantities of LIGHT to match new concrete to existing concrete or to produce a custom-color concrete. LIGHT is effective with virtually all types of cement mixtures and may be used in conjunction with all products of the Concrete Pharmacy®.

USE:

With Rapid Set® Mortar Mix (55-lb. bag), Cement All™ (55-lb. bag), Concrete (60-lb. bag), Stucco Patch (50-lb bag), WunderFixx® (50-lb bag), OnePass® (25-lb bag) and DOT Repair Mix (55-lb. bag), use up to 8 packets of LIGHT to achieve the desired color. A trial batch is recommended to fine-tune the color to match job requirements.

DIRECTIONS:

Dissolve LIGHT in the mixing water. Use enough LIGHT to achieve desired pigment tint. Follow product mixing instructions described on the package of the cement product. Use up to 8 packets per 50 to 60-lb. bag of cement product.

WARNING:

May cause skin, eye, and lung irritation. Avoid contact with skin, eyes, and clothing. Wash thoroughly after handling. Wear appropriate safety and protective equipment. *DO NOT TAKE INTERNALLY.* In case of contact, flush affected areas with water for 15 to 20 minutes. If irritation persists, seek medical attention. Wash contaminated clothing. Refer to Material Safety Data Sheet for more information.

LIMITED WARRANTY:

Seller warrants this product is free from defects in material and workmanship and this warranty will be limited to replacement of the product. *IT IS EXPRESSLY AGREED THAT THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF FITNESS AND MERCHANTABILITY.*